

Tomcat Edge Machine

Before use:

Pads: Make sure that you have the correct pads for your job. We sell a variety of different pads for all types of cleaning, and stripping. Machine uses a 14x20 pad and can be used wet or dry.

Stripper: make sure that you have the stripper of your choice if you choose to use a stripper, with a SPP pad you don't need to use stripper.

Operation:

Plug in machine: Plug machine in to an outlet that nothing else is plugged into, do not plug into an extension cord.

Handle Adjustment: At the bottom of handle is a lever to adjust the handle to your desired comfort.

Pad: Put your desired pad on the machine. Red pad must be used as a spacer pad between the grip face, and your surface prep, or stripping pad.

Get to work: When all above is done and you are ready to start pull the levers on the handle to start up the machine and proceed cleaning floor by moving forward.

After use:

Clean Machine: Please wipe down the cord, and the base of the machine.

Pad: Make sure that either a red or white pad is under the machine when you are done. Never transport or put machine on grip face without a pad under it.

Thank you for renting from Bell Janitorial Supply, we look forward to renting to you again!!